

# Design Challenges of Digital Radiator Technology for Future NASA Space Missions


Daniel F. Berisford, Gajanana C. Birur, Jennifer R. Miller, Eric T. Sunada, Gani B. Ganapathi Jet Propulsion Laboratory, California Institute of Technology, Pasadena, CA

Ryan Stephan
NASA Johnson Space Center, Houston Texas, 77058

Presented at the Spacecraft Thermal Control Workshop March 8-10, 2011, El Segundo, CA



## Digital Radiator Basic Design






## Challenges

- Stopping flow in a leg
  - Fluid freezing
    - Fluid evacuation
      - –Restarting flow



# Stopping Flow in a "Leg"





## Fluid "Freezing"

PPG/ H2O -30°C (baseline)

• Therminol D-12 -100°C

MultiTherm ULT-170 -129°C

MultiTherm WB-58 -62°C

• Novec 7200 -138°C

• Galden HT-170 -97°C

• QTherm SZ2 -50°C



# Freeze Experiment Setup


Lexan containment box for GN2 purge

GN2 purge line

Heat x-changer cup


Bulk fluid T Inside wall T (replaced by datalogger)

Mag. Stir plate






# Freeze Experiment Setup (top view)





#### Unstirred freeze test (50 min bet 1st and last frame)





## Concentration analysis

PPG percentage measured in sample of unfrozen liquid

Results show little concentration change




#### Freeze video



- In this video, the liquid begins at bulk T=-29C.
  At the start of the video, the chiller is set to -38C, which drops the wall T to -35C.
  Final bulk T = -35C
- The post-freeze clip at the end is after 40 minutes of unstirred freezing. Bulk T=-57C

## Thermocouple data from unstirred test





# Qtherm freeze test

(Temp at center, 70 min. time)



Initial State > 0 C



Frozen -30 C



Cooling -5 C



(Hand stir) Broken up -30 C




Freezing -26 C



Thawing -10 C



## **Qtherm TC data unstirred**



## Lessons Learned from Freeze Tests

Freezing behavior not well characterized

Difficult to predict flow-stopping T

Must fully evacuate fluid from stopped legs




## Fluid Evacuation Experiments

- Test of different evacuation techniques
  - Vacuum pump
  - Vent to space
  - Dissolved CO<sub>2</sub>
  - Bubble Injection
  - Heater/ pump




# Dissolved CO<sub>2</sub> Experiment






# Dissolved CO<sub>2</sub> Experiment



Fails to evacuate due to uniform bubble forming all over tube




# Dissolved CO<sub>2</sub> Experiment






# **Bubble Injection Experiment**






# **Bubble Injection Experiment**



- Evacuates well
- Added complexity to S/C to remove gas




## Startup Heater Experiment





## Startup Heater Experiment



Successful
 evacuation in 45s
 with 35W heater
 power.


Works w/ favorable and adverse gravity

Video: single tube 12ft heater evac-cut.wmv



## Multiple Tube Evacuation

- Evacuation of three tubes with individual heaters demonstrated successfully.
- ~15% of fluid remains in each tube due to adhesion to walls.





## Incomplete Evacuation

- 15% of fluid remains in tube as film on walls due to surface tension for all techniques.
  - Occurs for polycarbonate, teflon, Al tubes

 This fluid coalesces into "clots" to block flow upon freezing

Use internally finned tubes to combat



## Internally Finned Tubing


 Tube with internal fins to trap excess fluid by capillary action.





## Internally Finned Tubing Experiment

- Smooth and finned tubes attached to chiller line to freeze remaining fluid
- Post freeze flow test to indicate blockage
  - Finned tube flows
  - Smooth tube no flow





#### Summary

- Coolant freezing behavior not well defined
- Evacuation of stagnant fluid necessary
- Stub heater evacuation method is promising
- Internally finned tubes prevent blockage



## Supplementary

The following slides are for back-up QA purposes



#### Test results

- 50/50 PPG/H<sub>2</sub>O mix behaves according to literature
- Liquid becomes opaque and highly viscous at ~ -30C (bulk T) and mag. stirrer fails.
- This is not a hard freeze, but essentially useless beyond this point (except for stag. Rad.)




Fig 11 from "A Guide to Glycols" –Dow corporation, 2003

# PPG surface tension/ drop angle test

